



ASSEMBLY INSTRUCTIONS



Congratulations on your purchase of the Performance Games, Inc. home entertainment table. We want to ensure that you are completely satisfied with your purchase. So, please feel to contact either your dealer or Performance Games, Inc. for any assistance in the assembly of your new product or for any other information you may want or need.



Tools Needed for Assembly:

- Wrenches (included)
- Phillips Head Screw Driver
- 2 Foot Level

Content:

- IceBoxx Cabinet
- Legs
- Accessory Package
- Assembly Instructions

Quantity

- 1
- 4
- 1
- 1

Be sure to verify that all of the items listed above are included in the box before starting assembly.

ASSEMBLY PROCEDURE:

DUE TO THE WEIGHT AND SIZE OF THE TABLE, IT IS RECOMMENDED THAT (2) PEOPLE ASSEMBLE THE TABLE TOGETHER.

Step 1: Content Removal

- Carefully lift the IceBoxx cabinet out of the box and lay it on its side (opposite of the rods), placing it on a clean and smooth surface to avoid scratching the finish.
- Remove the legs from the box and locate the accessory package.

Step 2: Leg Assembly

- Assemble the legs by inserting the leg's threaded studs into and through the mounting pad holes.
- Secure with (1) washer and (1) lock nut on each stud.
- Tighten until nuts are flush with the leg pad surface.
- Repeat this process on each leg.

Step 3: Flip Table Over

- Check that all the leg levelers are screwed all the way into the legs.
- Carefully lift up and rotate the table onto its legs.
 - * DO NOT ALLOW WEIGHT OF TABLE TO ROCK ON ANY ONE OR TWO LEGS ALONE.
 - * We recommend that (2) or more people lift the table together.



ASSEMBLY PROCEDURE:

Step 4: Electronic Scoring Unit Assembly

** If scoring unit is already attached, jump to ★.*

- Attach the scoring unit by bolting it to the black brackets on the side of the dome using the (2) bolts, (2) washers, (2) nuts and (1) small screw provided.

** The (2) long screws are for the BladeRush and SlickIce games and should be disregarded.*

- Slip the bolts through the holes on the scoring unit and then through the black bracket. Tighten with the screw driver and wrench.

- Run the small screw through the small hole on the inside of the dome and into the scoring unit.

- ★ • Push the smaller end of the AC power cord into the rubber tube on the bottom of the table.

- Carefully pull the rubber tube through the top of the cabinet.

- The AC power cord should be through the hole in the top of cabinet. This will allow you to plug in the scoring unit without the cord hanging down the side of the cabinet.

- Locate the (2) wires coming out of the hole located on the hinge side of the dome. Connect them to the scoring unit.

** The scoring unit can be powered either by plugging the AC power cord into the power strip or by using (4) AA batteries (not included).*

- Test that the sensor wires are correctly attached by shooting a puck into one of the goal openings.
- If the scored goal credits the wrong team, simply switch the identical wires as they were plugged into the wrong position.

Step 5: Level the Games

- Adjust the leg levelers until the puck slides true on the playing surface.

- For more precise leveling, use a level.

- Place the level horizontally on the playing surface pointing towards the goal openings.

- Check that all the levelers are screwed all the way in as a starting point.

- Evenly adjust the leg levelers on one end until you are horizontally level.

- Turn the level 90 degrees so it is pointing towards the scoring unit.

- Evenly adjust the leveler on one side of the table until it is vertically level.

Step 6: Lubricating the Rods and Bushings

- Pull the rods away from the cabinet completely.

- Apply 2 or 3 drops of lubricant to each rod while rotating and pushing it back towards the cabinet to evenly spread the lubricant.

- Repeat as needed.

Specifications subject to change without notice.

Main Office:

15200 Smith Drive
Shakopee, MN 55379
Phone: 952-496-2919
Fax: 952-496-1889

Sales and Marketing:

Phone: 248-705-5395

www.PerformanceGamesInc.com